



ASSEMBLY INSTRUCTIONS



Before you start: The pointed side of the roof rack should face **forward** on the car roof.

1. Install the rubber strip in all three tracks.
2. Pull back 15–20 cm of the strip in the **lower track** and insert two **M8x16 mm** bolts.
Do not cut the list until later.



3. Mount the stainless steel bracket using two **M8 flange nuts**.

Tighten only by hand so that the bracket can slide back and forth.

NOTE! The bracket shown in the image may vary in design depending on the vehicle model. However, the installation principle is always the same.

4. Press the end caps into place.



5. Place the roof rack on the vehicle and **center** the brackets.

6. Push the lower rubber strip back into place up to the bracket and cut. Insert the cut-off piece **between the bracket and the end cap**.

7. Remove any rubber plug or screw covering the mounting point on the vehicle's roof. Install brackets using the included **M6** or **M8 screws**.

Use a torque wrench and tighten **M6** to **10 Nm** or **M8** to **25 Nm**.



We recommend using thread sealant around the screws going into the roof.